

HP用_OpenInfo対応表_NR-MZ50シリーズ

◆OpenInfoサービス対応機種一覧

docomo

分類	機種	Open Info	
A	iPhone5C	×	
	iPhone5S	×	
	iPhone6	×	
	iPhone6 Plus	×	
CA	CA-01C	○	
F	F-03B	○	
	F-06B	×	
	F-07B	○	
	F-01C	○	
	F-02C	○	
	F-03C	○	
	F-09C	○	
	F-10C	○	
	F-12C	×	
	F-01D	×	
	F-02D	○	
	F-03D	×	
	F-04D	○	
	F-05D	×	
	F-07D	○	
	F-08D	×	
	F-09D	×	
	F-10D	×	
	F-12D	×	
	F-01E	○	
	F-03E	×	
	F-04E	×	
	F-05E	×	
	HW	HW-01E	×
	L	L-03C	○
		L-04C	×
L-07C		×	
L-01D		×	
L-02D		×	
L-05D		×	
L-06D		×	
L-01E		×	
L-02E		×	

au

分類	機種	Open Info
A	iPhone4S	×
	iPhone5	×
	iPhone5C	×
	iPhone5S	×
	iPhone6	×
	iPhone6 Plus	×
CA	CA005	○
	CA006	○
	CA007	○
	G'zOne TYPE-X	○
	ISW11CA	×
	W63CA	○
F	CAL21	×
	F001	○
	ISW11F	×
	ISW13F	×
	IS12F	×
H	FJL21	×
	beskey	○
HTC	ISW11HT	×
	ISW12HT	×
	ISW13HT	×
	HTL21	×
K	HTL22	×
	SA002	○
	K007	○
L	K009	○
	K011	○
	ISW11K	×
	IS11LG	×
M	URBANO PROGRESSO	×
	KYL21	×
N	GRATINA	×
	LGL21	×
N	ISW11M	×
	IS12M	×
N	IS11N	×
	IS06	×

SoftBank

分類	機種	Open Info
A	iPhone3GS	×
	iPhone4	×
	iPhone4S	×
	iPhone5	×
	iPhone5C	×
	iPhone5S	×
DL	iPhone6	×
	iPhone6 Plus	×
DL	001DL	×
	101DL	×
F	101F	○
HT	X06HT	×
	X06HT II	×
HW	001HT	×
	007HW	×
HW	201HW	×
	K	101K
M	201M	×
	N	841N
001N		×
101N		×
P	001P	○
	003P	×
	101P	×
	102P	×
	103P	×
	930P	○
SC	941P	×
	942P	×
SC	941SC	×
	001SH	○
	002SH	○
	003SH	○
	004SH	○
	005SH	○
	006SH	○
	007SH	○
	009SH	○

N	N-02A	×
	N-06A	○
	N-01B	○
	N-04B	○
	N-07B	×
	N-08B	○
	N-02C	○
	N-03C	○
	N-04C	×
	N-05C	○
	N-06C	×
	N-01D	×
	N-02D	○
	N-04D	×
	N-05D	×
	N-06D	×
	N-07D	×
	N-08D	×
N-01E	○	
N-02E	×	
N-03E	×	
M	M702iS	○
P	P-07A	○
	P-01B	○
	P-04B	×
	P-06B	×
	P-03C	×
	P-05C	○
	P-07C	×
	P-01D	×
	P-02D	×
	P-04D	×
	P-05D	×
	P-06D	×
P-903i	○	
P-906i	○	
SC	GALAXY S(SC-02B)	×
	GALAXY Tab(SC-01C)	×
	GALAXY S II (SC-02C)	×
	SC-01D	×
	SC-02D	×
	GALAXY S II LTE (SC-03D)	×
	GALAXY NEXUS (SC-04D)	×

PT	IS11PT	×
	PTL21	○
SA	SA002	○
SH	SH001	○
	SH004	○
	SH007	○
	SH008	○
	SH009	○
	SH010	○
	SH011	○
	IS01	×
	IS03	×
	IS05	×
	IS12SH	×
	IS13SH	×
	IS14SH	×
	IS15SH	×
	ISW16SH	×
	IS17SH	×
	INFOBAR A01	×
	INFOBAR C01	×
	SHL21	×
	SHL22	×
SHT21	×	
S	S001	○
	S003	○
	S004	○
	S005	○
	S006	○
	S007	○
	URBANO MOND	○
	URBANO BARONE	○
	URBANO AFFARE	○
	G9	×
	G11	○
	IS11S	×
IS12S	×	
Walkman Phone Premier3(SOY01)	○	
SOL21	×	
SA	W63SA	○
SC	ISW11SC	×
	SCL21	×
	T004	○

SH	812SH	○
	841SH	○
	842SH	○
	933SH	○
	934SH	×
	942SH	○
	944SH	○
	945SH	○
	DM007SH	○
	DM008SH	○
	DM009SH	○
	841SHs	○
	DM010SH	○
	DM011SH	○
	DM012SH	○
	DM013SH	×
	101SH	○
	102SH	×
	102SH II	×
	103SH	○
104SH	×	
106SH	×	
107SH	○	
108SH	×	
109SH	○	
200SH	○	
202SH	○	
206SH	×	
Z	003Z	×
	008Z	×
	009Z	×

	SC-05D	x	
	SC-06D	x	
	SC-01E	x	
	SC-02E	x	
	SC-03E	x	
	SC-04E	x	
SH	SH-01B	O	
	SH-02B	O	
	SH-07B	x	
	SH-10B	x	
	SH-01C	O	
	SH-03C	x	
	SH-05C	O	
	SH-06C	O	
	SH-10C	O	
	SH-12C	x	
	SH-13C	x	
	SH-01D	x	
	SH-02D	x	
	SH-03D	O	
	SH-04D	x	
	SH-05D	O	
	SH-06D	x	
	SH-07D	x	
	SH-09D	x	
	SH-01E	x	
	SH-02E	x	
	S	Xperia(SO-01B)	x
		Xperia arc (SO-01C)	x
Xperia acro (SO-02C)		x	
Xperia ray (SO-03C)		x	
Xperia PLAY (SO-01D)		x	
SO-02D		x	
Xperia acro HD (SO-03D)		x	
SO-04D		x	
SO-01E		x	
SO-02E		x	
SO-04E		x	
T	T-01B	x	
	T-01C	x	
	T-01D	x	
	T-02D	x	

T	T005	O
	T006	O
	T007	O
	T008	O
	LIGHT POOL	O
	X-RAY	O
	IS04	x
	IS11T	x
	IS12T	x
	W61T	O