

三菱電機製 洗濯機 形名順販売年度一覧表

全自動洗濯機

形名	販売開始年
AW-10	1981
AW-150G	1983
AW-150W	1983
AW-250G	1979
AW-260A	1981
AW-260G	1981
AW-265A	1981
AW-265G	1981
AW-265W	1983
AW-280G	1983
AW-280W	1983
AW-285G	1984
AW-285GN	1984
AW-285W	1984
AW-285-WH	1987
AW-30(乃カメ)	1983
AW-3000	1974
AW-300G	1978
AW-300W	1978
AW-300Y	1978
AW-3100	1974
AW-310A	1979
AW-310G	1979
AW-310Y	1979
AW-3200	1969
AW-3300	1969
AW-3400	1973
AW-3450P	1973
AW-3450PH	1973
AW-3460	1974
AW-3460P	1974
AW-3500	1973
AW-3500P	1973
AW-3560	1974
AW-3600	1972
AW-3600H	1972
AW-3600P	1972
AW-3600PH	1972
AW-3700	1971
AW-3700B	1972
AW-3700P	1972
AW-3800	1971
AW-3900	1972
AW-400A	1979
AW-405A	1980
AW-407A	1982
AW-407W	1983
AW-410A	1980
AW-415A	1982
AW-415W	1983
AW-42A1	1996
AW-42B1	1998
AW-42C1	1999
AW-42D1	2002
AW-4700	1975
AW-4800	1973
AW-5000C	1974
AW-6000C	1976
AW-7000	1975
AW-7000P	1975
AW-7100	1975
AW-7500	1976
AW-7600	1977
AW-8000	1976
AW-8000N	1977
AW-8300	1977
AW-8300G	1977
AW-8300N	1978
AW-A45-AP	1989
AW-A45G1-C	1992
AW-A45G1-H	1992
AW-A45-W	1989
AW-A50C2-BE	1991
AW-A50C3-C	1992
AW-A50C3-H	1992
AW-A50F2-BE	1991
AW-A50F2-EG	1991
AW-A50F2-WH	1991
AW-A50-W	1989
AW-A60-AP	1989
AW-A60B1-EG	1990
AW-A60B1-WH	1990
AW-A60C1-BE	1990
AW-A60C1-EG	1990

形名	販売開始年
AW-A60C1-WH	1990
AW-A60C2-C	1991
AW-A60C2-H	1991
AW-A60C2-W	1991
AW-A60-EG	1989
AW-A60F1-BE	1990
AW-A60F1-EG	1990
AW-A60F1-WH	1990
AW-A60F2-C	1991
AW-A60F2-H	1991
AW-A60F2-W	1991
AW-A60G1-C	1992
AW-A60G1-H	1992
AW-A60P1-C	1992
AW-A60P1-H	1992
AW-A60P1-T	1992
AW-A60-W	1989
AW-A80V1-CD	1991
AW-A80V1-T	1991
AW-AZ50-H	1993
AW-AZ60-H	1993
AW-B60-EG	1989
AW-B60-W	1989
AW-C60S-EG	1989
AW-C60S-W	1989
AW-E60-AP	1990
AW-E60-EG	1990
AW-E60-W	1990
AW-K360BE	1985
AW-K360WR	1984
AW-K361AP	1985
AW-K361GN	1985
AW-K361WR	1985
AW-K36AD-W	1985
AW-K380-AP	1985
AW-K380-BE	1985
AW-K382-AP	1986
AW-K382-G	1986
AW-K382-WH	1986
AW-K383-AP	1986
AW-K383-G	1986
AW-K383-WH	1986
AW-K38AD-AP	1986
AW-K38AD-WH	1986
AW-K420-AP	1988
AW-K420-W	1988
AW-K505-AP	1987
AW-K505-G	1987
AW-K505-WH	1987
AW-K508-W	1988
AW-K50AD-AP	1987
AW-K50AD-WH	1987
AW-K600-AP	1987
AW-K600-W	1987
AW-K605-AP	1988
AW-K605-EG	1988
AW-K605-W	1988
AW-KD50-WH	1987
AW-S60D	1988
AW-Z760-EG	1990
AW-Z850-H	1991
AW-Z860-EG	1990
MAW-105-H	1995
MAW-106-H	1995
MAW-50J1-C	1995
MAW-50J1-H	1995
MAW-50K-H	1996
MAW-50L-H	1997
MAW-50LP-H	1998
MAW-50M-H	1998
MAW-50MP-H	1998
MAW-50Q-H	1999
MAW-50QP-H	1999
MAW-50R-H	2000
MAW-50RP-H	2000
MAW-50S-H	1997
MAW-511-H	1999
MAW-55X	2005
MAW-55Y	2007
MAW-55-H	2001
MAW-5SP-H	2001
MAW-5T	2002
MAW-5U	2003
MAW-5U2	2004

形名	販売開始年
MAW-5W	2005
MAW-60AP	2012
MAW-60J1-C	1995
MAW-60J1-H	1995
MAW-60K-H	1996
MAW-60KP-C	1996
MAW-60KP-H	1996
MAW-60L-H	1997
MAW-60LP-C	1997
MAW-60LP-H	1997
MAW-60M-H	1998
MAW-60MP-H	1998
MAW-60Q-H	1999
MAW-60QP-H	1999
MAW-60R-H	2000
MAW-60RP-H	2000
MAW-60S-H	2001
MAW-60SP-H	2001
MAW-60TP-W	2002
MAW-611-H	1999
MAW-612P-H	2000
MAW-62X	2005
MAW-62Y	2007
MAW-6TPV5-AP	2002
MAW-6U	2003
MAW-6U2	2004
MAW-6W	2005
MAW-70AP	2012
MAW-70KP-C	1996
MAW-70KP-H	1996
MAW-70L-H	1997
MAW-70LP-C	1997
MAW-70LP-H	1997
MAW-70M-H	1998
MAW-70MP-C	1998
MAW-70MP-H	1998
MAW-70Q-H	1999
MAW-70QP-H	1999
MAW-70R-H	2000
MAW-70RP-H	2000
MAW-70S-H	2001
MAW-70SP-H	2001
MAW-711P-H	1999
MAW-712P-H	2000
MAW-715P	2002
MAW-716P	2004
MAW-815P	2002
MAW-816P	2004
MAW-CHV8UP-AG	2003
MAW-D6L-H	1997
MAW-D7TP-R	2003
MAW-D7TP-W	2002
MAW-D7UP-D	2003
MAW-D7UP-W	2003
MAW-D7WP-W	2004
MAW-D7XP-P	2005
MAW-D7XP-W	2005
MAW-D7YP-P	2006
MAW-D7YP-W	2006
MAW-D8TP-R	2003
MAW-D8TP-W	2002
MAW-D8UP-D	2003
MAW-D8UP-W	2003
MAW-D8WP-D	2004
MAW-D8WP-W	2004
MAW-D8XP-H	2005
MAW-D8XP-W	2005
MAW-D8YP-P	2006
MAW-D8YP-W	2006
MAW-D9WP-A	2004
MAW-D9WP-W	2004
MAW-D9XP-H	2005
MAW-D9XP-W	2005
MAW-D9YP-P	2006
MAW-D9YP-W	2006
MAW-D9YP-W	2006
MAW-EG6P-H	1999
MAW-EG6RP-H	2000
MAW-EG6SP-H	2001
MAW-F70P-W	2005
MAW-F80P-W	2005
MAW-F90P-W	2005
MAW-FV7TP-AP	2002
MAW-FV8TP-AP	2002

三菱電機製 洗濯機 形名順販売年度一覧表

全自動洗濯機

形名	販売開始年
MAW-GD108Y-N	2005
MAW-H75V6-AP	2003
MAW-H75V7-WA	2004
MAW-H85V6-AP	2003
MAW-HD66Y-P	2005
MAW-HD88X-S	2005
MAW-HD88Y-W	2005
MAW-HV6UP-AG	2003
MAW-HV6WP-W	2004
MAW-HV7UP-AG	2003
MAW-HV7UP-HS	2003
MAW-HV7WP-G	2004
MAW-HV7WP-W	2004
MAW-HV7XP-P	2005
MAW-HV7XP-W	2005
MAW-HV7YP-W	2006
MAW-HV8UP-AG	2003
MAW-HV8UP-HS	2003
MAW-HV8WP-G	2004
MAW-HV8WP-W	2004
MAW-HV8XP-W	2005
MAW-HV8YP-W	2006
MAW-HV9WP-G	2004
MAW-HV9WP-W	2004
MAW-HV9XP-W	2005
MAW-HV9YP-W	2006
MAW-K5TP-W	2002
MAW-K6-H	1996
MAW-KP7-H	1996
MAW-KV7WP-W	2004
MAW-KV8WP-W	2004
MAW-KV9WP-W	2004
MAW-LP6-H	1997
MAW-MP7-H	1998
MAW-MV7UP-R	2003
MAW-MV8UP-R	2003
MAW-N6UP-W	2003
MAW-N6WP-W	2004
MAW-N6XP-W	2005
MAW-N7TP-W	2002
MAW-N7UP-W	2003
MAW-N7WP-W	2004
MAW-N7XP-W	2005
MAW-N7YP-W	2006
MAW-N8TP-W	2002
MAW-N8UP-W	2003
MAW-N8WP-W	2004
MAW-N8XP-W	2005
MAW-N8YP-W	2006
MAW-N9WP-W	2004
MAW-N9XP-W	2005
MAW-N9YP-W	2006
MAW-R7T-W	2002
MAW-S90-W	2005
MAW-V6RP-H	2000
MAW-V6SP-S	2001
MAW-V6TP-W	2002
MAW-V7JP-H	1998
MAW-V7MP-C	1998
MAW-V7MP-H	1998
MAW-V7QP-C	1999
MAW-V7QP-H	1999
MAW-V7RP-C	2000
MAW-V7RP-H	2000
MAW-V7SP-H	2001
MAW-V7SP-S	2001
MAW-V7TP-A	2002
MAW-V7TP-W	2002
MAW-V7UP-S	2003
MAW-V8MP-C	1998
MAW-V8MP-H	1998
MAW-V8QP-C	1999
MAW-V8QP-H	1999
MAW-V8RP-C	2000
MAW-V8RP-H	2000
MAW-V8SP-H	2001
MAW-V8SP-S	2001
MAW-V8TP-A	2002
MAW-V8TP-W	2002
MAW-V8UP-S	2003
MAW-VB7P-H	1998
MAW-YM70UP-W	2003
MAW-YM80UP-W	2003
MAW-YP7-H	1999

全自動洗濯機

形名	販売開始年
MAW-Z6B-H	1996
MAW-Z6C-H	1997
MAW-Z6CL-H	1995
MAW-Z6D-H	1998
MAW-Z6E-H	1999
MAW-Z6F-H	2000
MAW-Z6H-H	2001
MAW-Z7DP-H	1998
MAW-Z7EP-H	1999
MAW-Z7FP-H	2000
MAW-Z7HP-H	2001
MAW-ZP7B-C	1996
MAW-ZP7C-C	1997
MVW-VD1-S	2007
MVW-VD1-W	2007

三菱電機製 洗濯機 形名順販売年度一覧表

二槽式洗濯機

形名	販売開始年
CW-101-H	1994
CW-1200	1972
CW-122DW	1985
CW-1500	1972
CW-1600	1973
CW-1700	1973
CW-1700P	1973
CW-1750	1973
CW-1800	1973
CW-221GN	1984
CW-221W	1984
CW-222G	1986
CW-222GN	1985
CW-222WP	1985
CW-223G	1986
CW-223WH	1986
CW-22ADW	1984
CW-22DG	1983
CW-22DW	1983
CW-28DA	1981
CW-301GN	1984
CW-301W	1984
CW-30CD-EG	1988
CW-30CD-W	1988
CW-30DG	1983
CW-30DPK	1983
CW-30DW	1983
CW-364-G	1988
CW-364-W	1988
CW-366T-EG	1988
CW-366T-G	1988
CW-366T-W	1988
CW-381W	1984
CW-401-G	1988
CW-401-W	1988
CW-40D-EG	1988
CW-5000	1976
CW-5100	1976
CW-5200	1977
CW-5300	1977
CW-5400	1977
CW-5400P	1977
CW-5500G	1977
CW-5500Y	1977
CW-600	1978
CW-6000	1968
CW-6080P	1970
CW-6100	1970
CW-611	1979
CW-6150	1971
CW-6200	1972
CW-6200B	1972
CW-620A	1979
CW-620G	1979
CW-621A	1980
CW-621G	1980
CW-625A	1981
CW-625G	1981
CW-6300	1971
CW-630A	1980
CW-630G	1980
CW-635A	1982
CW-635G	1982
CW-635W	1983
CW-6400	1971
CW-640A	1981
CW-640G	1981
CW-640W	1983
CW-6500	1971
CW-6500P	1972
CW-650P	1979
CW-650PA	1988
CW-650PW	1988
CW-6550P	1973
CW-655G	1983

形名	販売開始年
CW-655W	1983
CW-6600	1969
CW-660G	1983
CW-660W	1983
CW-7000	1968
CW-7000(カラー)	1968
CW-7000L	1968
CW-700G	1978
CW-700P	1966
CW-700Y	1978
CW-7050P	1968
CW-7060P	1970
CW-710	1979
CW-7100	1968
CW-720A	1980
CW-720G	1980
CW-720P	1967
CW-7300	1969
CW-730A	1980
CW-730G	1980
CW-7400	1971
CW-7400B	1971
CW-740A	1982
CW-740W	1983
CW-755	1965
CW-760	1965
CW-765	1967
CW-770	1966
CW-7700	1969
CW-7700D	1970
CW-780	1966
CW-780(B)	1966
CW-780(P)	1966
CW-785	1967
CW-785(B)	1967
CW-785(B/P)	1967
CW-785C(B)	1967
CW-785C(P)	1967
CW-788(青)	1967
CW-788(茶)	1967
CW-788(白)	1967
CW-788B	1968
CW-790	1967
CW-791	1968
CW-8000	1974
CW-8000P	1974
CW-800A	1979
CW-800G	1979
CW-8020	1974
CW-8020P	1974
CW-810A	1980
CW-810G	1980
CW-8120	1974
CW-8220	1975
CW-8220P	1975
CW-8280	1976
CW-830A	1980
CW-8320	1974
CW-8520	1975
CW-910W	1982
CW-980G	1983
CW-980GN	1984
CW-980W	1983
CW-A30-G	1989
CW-A30-W	1989
CW-A36-G	1989
CW-A36-W	1989
CW-A42-EG	1989
CW-A42-G	1989
CW-A42-W	1989
CW-AZ30-H	1992
CW-AZ42-H	1992
CW-B30D-EG	1989
CW-B30D-W	1989
CW-C30A1-H	1992

形名	販売開始年
CW-C36A3-H	1994
CW-C42S1-BE	1990
CW-C42S1-EG	1990
CW-C42S1-WH	1990
CW-C42S2-C	1992
CW-C42S2-H	1992
CW-C42S2-W	1992
CW-C42S3-C	1994
CW-C42S3-H	1994
CW-C43A1-H	1999
CW-C43K-H	1999
CW-C50S1-BE	1991
CW-C50S1-EG	1991
CW-C50S2-C	1992
CW-C50S2-H	1992
CW-C52S3-H	1994
CW-C55A1-H	1999
CW-C55S2-C	1992
CW-D22WH	1988
CW-K300GN	1984
CW-K300WB	1984
CW-K300WR	1984
CW-K30ADR	1984
CW-K30ADS	1984
CW-K330-AP	1986
CW-K330-G	1986
CW-K330-W	1986
CW-K330-WH	1987
CW-K331-W	1988
CW-KD305-W	1986
CW-M300DW	1985
CW-M300D-WH	1987
CW-M304-G	1986
CW-M304GN	1985
CW-M304P-W	1986
CW-M304WG	1985
CW-M304WHG	1987
CW-M304WHR	1986
CW-M304WR	1985
CW-M331-AP	1986
CW-M331-G	1986
CW-M331-W	1986
CW-M331-WH	1987
CW-M380	1984
CW-M381GN	1985
CW-M400-G	1986
CW-M400-W	1986
CW-M400-WH	1987
CW-S30-W	1990
CW-S36-G	1990
CW-S36-W	1990
CW-S42EG	1989
CW-S42W	1989
CW-Z43A1-H	1999
CW-Z730-W	1990
CW-Z742-EG	1990
CW-Z842-EG	1990

三菱電機製 洗濯機 形名順販売年度一覧表

自動二槽式洗濯機

形名	販売開始年
AW-8200	1969
CWA-1100	1976
CWA-1150	1977
CWA-800	1966
CWA-850A	1980
CWA-850W	1983
CWA-880GN	1984
CWA-880W	1982
CWA-K303S-WR	1985
CWA-K365S-W	1988
CWA-K36M3-H	1994
CWA-880G	1982
CWA-K303S-WS	1985
CWA-K303S-G	1986
CWA-K303S-WH	1987
CWA-K365S-G	1988